


3+

Barbie INSTRUCTIONS

L8586-0920



For U.S.A. market only:  
We want you to have fun playing with our products.  
Please give us your feedback by filling out the short on-line  
survey. Go to :  
[service.mattel.com/surveys](http://service.mattel.com/surveys)  
Thanks for helping us make great toys even better!

English-only site

#### CONSUMER INFORMATION

Need Assistance? Visit [service.mattel.com](http://service.mattel.com) or call 1-800-524-8697  
(US and Canada only), M-F 9AM - 7PM & SAT 11AM - 5PM, Eastern.

[SERVICE.MATTEL.COM](http://SERVICE.MATTEL.COM)

Mattel Canada Inc., Mississauga, Ontario L5R 3W2. You may call us free at/ Composez sans frais le 1-800-524-8697.  
[Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB](http://Mattel.U.K.Ltd.VanwallBusinessPark.MaidenheadSL64UB), Helpline 01628 500303.  
Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312.  
Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.  
Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Tel:03-78803817, Fax:03-78803867.  
Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245 U.S.A. Consumer Relations 1 (800) 524-8697.



Contents: Please remove everything from the package and compare to the contents shown here. If any items are missing, please contact your local Mattel office. Keep these instructions for future reference as they contain important information.

**WARNING:**  
**CHOKING HAZARD** - Small parts.  
Not for children under 3 years.


## PLAY TIME!

Rotate butterfly knob clockwise, doll's head turns to left as butterfly swirls up her arm. When knob is released gently, butterfly swirls back down her arm and doll's head turns forward.

**If knob does not return to the original upright position, manually rotate it counterclockwise.**



If butterfly does not swirl down from doll's upper arm, slightly turn butterfly knob counterclockwise.



**REMOVABLE WINGS!**

Doll cannot stand alone.

Doll's left arm contains a magnet. Do not use around items that are sensitive to or affected by magnetic fields. Butterfly contains a magnet.